

DS Instruments - Phase Shifter SCPI Command List (V3)

Command	Example 1	Example 2	Description
PHASE	PHASE 90	PHASE -30	Set phase shift in degrees
PHASE?			Return current phase setting
ATT	ATT 13.25	ATT 10.5	Set output step attenuator value
ATT?			Return attenuator setting
OUTP:STAT	OUTP:STAT ON	OUTP:STAT OFF	Enable or disable the RF output
OUTP:STAT?			Return the output state
*IDN?			Return the SCPI identification string
*PING?			returns "PONG!" if device is responding
SYST:DBG?			return the last debug message
SYST:ERR?			Returns any pending error codes
*RST			Reset unit now
*DISPLAY	*DISPLAY OFF	*DISPLAY ON	Power on of off the display
*BUZZER	*BUZZER ON	*BUZZER OFF	Mute the buzzer
*SAVSTATE			Save frequency & attenuation as boot defaults
*UNITNAME	*UNITNAME Bob	*UNITNAME DEV-34	Set a unique name in flash memory
*UNITNAME?			Return this device's name

Command terminator is LINEFEED ("\\n")

Version 1.5 - (COM BAUD: 115200)